



10_End_of_pipe_string



Drain valve at the end of pipe for letting off air and stagnant water inside the pipe.



Nozzle at the end of pipe for letting off air and stagnant water inside the pipe.

