

16_Service_low_pressure_solenoid_valve



16_Service_low_pressure_solenoid_valve



This small hole must be open if the pilot controlled solenoid valve operates.

